


TYPE 3

⚠ WARNING
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.




Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530071459	Air Dam (kit)	20.	545018204	Assy. -Housing-RH(Incl. 21)
2.	530071458	Gasket-Adapter (kit)	21.	530402044	Spring-Cover Latch
3.	530035561	Carburetor Adaptor	22.	530049617	Guide-Starter Rope
4.	530016441	Screw	23.	545018103	Housing-Left
5.	530071458	Gasket-Carburetor (kit)	24.	530036792	Isolator-Crankcase
6.	---	Kit-Carb Ass'y.	25.	530049491	Assy-Fuel Tank
	530071632	(C1Q-W11C)	26.	530049527	Gasket-Fuel Tank
	530071775	(WT-606)	27.	530049386	Fuel Cap w/Retainer
7.	530056629	Air Box	28.	530049656	Grommet-Shroud
8.	530015849	Screw-Carb.	29.	530069247	Kit-Line Carb/Purge
9.	530049383	Filter-Air	30.	530069216	Kit-Line Tank/Purge
10.	530056581	Cover-Air Filter	31.	530095646	Assy-Fuel Pick-up
11.	530016349	Screw	32.	530071459	Grommet-Fuel line (kit)
12.	545085001	Guard-Muffler	33.	530023877	Fitting-Fuel line
13.	530095469	Handle			
14.	530071459	Foam 71.12mm (kit)			
15.	530015886	Screw			Not Shown
16.	530049323	Isolator			
17.	530015197	Nut			
18.	545003502	Screw	✓	545117588	Manual-Operator's
19.	530071458	Heat reflector (kit)		530057414	Decal-Warning
				545003020	Decal-CE Warning
				530402633	Decal-Screw Warning

TYPE 1



WARNING

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.



Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	952030249	Spark Plug (RCJ-6Y)	21.	530015941	Retainer Ring-C'chaft	40.	530049313	Inlet Door
2.	530015953	Screw	22.	530016190	Spacer-Flywheel	41.	530095461	Assy-Mulch Blade
3.	530055191	Insulator-Heat	23.	530015149	Washer	42.	530069817	Assy-Impeller
4.	530016387	Screw-Muffler-Internal	24.	530039209	Assy-Flywheel	43.	530056625	Seal-Ring
5.	530015241	Screw	25.	530071456	Assy-Crankcase/Crank shaft (incl. 21,26,28)	44.	530016349	Screw
6.	530071593	Kit-Spark Screen (incl. #5)	26.	530012492	Assy-Crankcase (Incl. 19,20,27)	45.	530055101	Housing-Pulley
7.	530071834	Kit-Muffler (incl. 4,5,6, & 8)	27.	530032125	Bearing-Inner	46.	530042086	Spring-Starter
8.	530071458	Gasket-Baffle (kit)	28.	530012452	Assy-Crankshaft	47.	530071466	Kit-Starter Pulley
9.	530071458	Gasket-Cylinder (kit)	29.	530071458	O-ring-C/case (kit)	48.	530055102	Fan Housing
10.	530071457	Kit-Cylinder	30.	530012443	Cover-Crankcase	49.	530015810	Screw
11.	530019182	Grommet-Ign. Module	31.	530015810	Screw	50.	530071459	Foam-182mm (kit)
12.	530016357	Screw-Ignition Module	32.	530071459	Foam-219mm (kit)	51.	530071458	Kit-Gasket (page 1 incl. 2, 5, 19) (page 4 incl. 8,9, 29)
13.	530035505	Ignition Module	33.	530029182	Eyelet-Flange	52.	530071459	Kit-Foam Seals (page 1 incl. 1,14, 32) (page 4 incl. 32, 50)
14.	530071833	Kit-Piston (Incl. 16, 17)	34.	530071467	Kit-Rope (Incl. 36)			
15.	530071785	Kit-Piston/Rod (Incl. 14,18)	35.	530049488	Handle-Starter			
16.	530055120	Piston Ring	36.	530016391	Screw-Rope			
17.	530015162	Retainer-Piston Pin	37.	530016402	Washer-Belleville			
18.	530069945	Assy-Connecting Rod	38.	530626605	Nut			
19.	530019264	Seal	39.	530402043	Spring-Return Cover			
20.	530055728	Bearing-Outer						

✓ = NEW PART NUMBER FOR THIS IPL


★ = REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)

TYPE 2



WARNING

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.




Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	952030249	Spark Plug (RCJ-6Y)	21.	530015941	Retainer Ring-C'chaft	40.	530049313	Inlet Door
2.	530015953	Screw	22.	530016190	Spacer-Flywheel	41.	530095461	Assy-Mulch Blade
3.	530055191	Insulator-Heat	23.	530015149	Washer	42.	530069817	Assy-Impeller
4.	530016387	Screw-Muffler-Internal	24.	530039209	Assy-Flywheel	43.	545078801	Seal-Ring
5.	530015241	Screw	25.	530071456	Assy-Crankcase/Crank shaft (incl. 21,26,28)	44.	530016349	Screw
6.	530071593	Kit-Spark Screen (incl. #5)	26.	530012492	Assy-Crankcase (Incl. 19,20,27)	45.	545079101	Housing-Pulley
7.	530071834	Kit-Muffler (incl. 4,5,6, & 8)	27.	530032125	Bearing-Inner	46.	530042086	Spring-Starter
8.	530071458	Gasket-Baffle (kit)	28.	530012452	Assy-Crankshaft	47.	530071466	Kit-Starter Pulley
9.	530071458	Gasket-Cylinder (kit)	29.	530071458	O-ring-C/case (kit)	48.	545079001	Fan Housing
10.	530071457	Kit-Cylinder	30.	545064601	Cover-Crankcase	49.	530015810	Screw
11.	530019182	Grommet-Ign. Module	31.	530015810	Screw	50.	530071459	Foam-182mm (kit)
12.	530016357	Screw-Ignition Module	32.	530071459	Foam-219mm (kit)	51.	530071458	Kit-Gasket (page 2 incl. 2, 5, 19) (page 5 incl. 8,9, 29)
13.	530035505	Ignition Module	33.	530029182	Eyelet-Flange	52.	530071459	Kit-Foam Seals (page 2 incl. 1,14, 32) (page 5 incl. 32, 50)
14.	530071833	Kit-Piston (Incl. 16, 17)	34.	530071467	Kit-Piston (Incl. 36)			
15.	530071785	Kit-Piston/Rod (Incl. 14,18)	35.	530049488	Handle-Starter			
16.	530055120	Piston Ring	36.	530016391	Screw-Rope			
17.	530015162	Retainer-Piston Pin	37.	530016402	Washer-Belleville			
18.	530069945	Assy-Connecting Rod	38.	530626605	Nut			
19.	530019264	Seal	39.	530402043	Spring-Return Cover			
20.	530055728	Bearing-Outer						

✓ = NEW PART NUMBER FOR THIS IPL

★ = REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)

TYPE 3

WARNING
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.




Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	952030249	Spark Plug (RCJ-6Y)	21.	530015941	Retainer Ring-C'chaft	40.	530049313	Inlet Door
2.	530015953	Screw	22.	530016190	Spacer-Flywheel	41.	530095461	Assy-Mulch Blade
3.	530055191	Insulator-Heat	23.	530015149	Washer	42.	530069817	Assy-Impeller
4.	530016387	Screw-Muffler-Internal	24.	530039209	Assy-Flywheel	43.	530056625	Seal-Ring
5.	530015241	Screw	25.	530071456	Assy-Crankcase/Crank shaft (incl. 21,26,28)	44.	530016349	Screw
6.	530071593	Kit-Spark Screen(incl. #5)	26.	530012492	Assy-Crankcase (Incl. 19,20,27)	45.	530055101	Housing-Pulley
7.	530071834	Kit-Muffler (incl. 4,5,6, & 8)	27.	530032125	Bearing-Inner	46.	530042086	Spring-Starter
8.	530071458	Gasket-Baffle (kit)	28.	530012452	Assy-Crankshaft	47.	530071466	Kit-Starter Pulley
9.	530071458	Gasket-Cylinder (kit)	29.	530071458	O-ring-C/case (kit)	48.	530055102	Fan Housing
10.	530012432	Cylinder	30.	545064601	Cover-Crankcase	49.	530015810	Screw
11.	530019182	Grommet-Ign. Module	31.	530015810	Screw	50.	530071459	Foam-182mm (kit)
12.	530016357	Screw-Ignition Module	32.	530071459	Foam-219mm (kit)	51.	530071458	Kit-Gasket (page 3 incl. 2, 5, 19) (page 6 incl. 8,9, 29)
13.	530035505	Ignition Module	33.	530029182	Eyelet-Flange	52.	530071459	Kit-Foam Seals (page 3 incl. 1,14, 32) (page 6 incl. 32, 50)
14.	530071833	Kit-Piston (Incl. 16, 17)	34.	530071467	Kit-Rope (Incl. 36)			
15.	530071785	Kit-Piston/Rod (Incl. 14,18)	35.	530049488	Handle-Starter			
16.	530055120	Piston Ring	36.	530016391	Screw-Rope			
17.	530015162	Retainer-Piston Pin	37.	530016402	Washer-Belleville			
18.	530069945	Assy-Connecting Rod	38.	530626605	Nut			
19.	530019264	Seal	39.	530402043	Spring-Return Cover			
20.	530055728	Bearing-Outer						

↙ = NEW PART NUMBER FOR THIS IPL

★ = REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)

Assy - Vacuum




Ref.	Part No.	Description
1.	530095564	Assy-Vac. Bag w/strap
2.	545086401	Tube-Elbow Vac
3.	530071970	Kit-Lower Vac (Incl. 4)
4.	530402528	Screw
5.	530056901	Tube-Upper Vac
6.	530095593	Tube-Blower

Kit - Carburetor Assy # 530071632 - C1Q-W11C (zama)

Kit - Carburetor Assy # 530071775 - WT-606 (walbro)

530071716-Kit-Choke Lever (zama)
530071725-Kit-Choke Lever (walbro)



530071715-Kit-Throttle Lever (zama)
530071726-Kit-Throttle Lever (walbro)

Note: No Repair kits are available for this carburetor, please order the complete assembly part number